




ASSEMBLY MANUAL

Siegen SG1 (electronic lock)


1. Disassembly of the drawer.

Open the drawer using the code, take out the battery.
In order to take out the drawer, remove the screw with an allen key (3mm), remove the bumper (A).
Then move the lever of the rail to the left (B), pulling out the drawer at the same time.



2. Anchoring the body to the wall.

In order to anchor the drawer, the holes plugs, which will be used, have to be removed (C).
Make sure the body is well-levelled after anchoring (G).



3. Assembly of the drawer in the body.

Make sure that the drawer hook (E) is in vertical position.

Hold the drawer vertically and slip the inner rail of the drawer into the outer rail of the body.

The first slide inwards may require more force, but once the slides have interlocked, the drawer should slide in and out smoothly.
Slide the drawer completely into the cabinet until the rail clicks into place. Re-insert the drawer completely and release, check that it extends itself to the correct distance.

Slide the drawer in just enough to fit the bumper (F).

With the drawer open, insert the battery, then slide the drawer in fully and hold for approximately 3 seconds.

Apply the 3 second rule every time you close the drawer.

